


Κατεβάστε και εγκαταστήστε το πρόγραμμα **SADPTool** μέσω του παρακάτω συνδέσμου:


<https://www.hikvision.com/europe/support/tools/hitools/TS20200826033/>

1. Αρχικοποίηση

- Συνδέστε τη κάμερα με το καλώδιο τροφοδοσίας και με ένα καλώδιο δικτύου στο modem router
- Ανοίξτε το πρόγραμμα έπειτα από την επιτυχή εγκατάστασή του




1. Επιλέξτε τη συσκευή που θέλετε να αρχικοποιήσετε
2. Ορίστε τον επιθυμητό κωδικό πρόσβασης
3. Επιλέξτε “**Activate**”




Θα λάβετε το μήνυμα “**The device is activated**” κατά την επιτυχή αρχικοποίηση της κάμερας

2. Ενεργοποίηση Λειτουργίας Wi-Fi

Πραγματοποιήστε είσοδο στο μενού της κάμερας μέσω IP. Προτείνεται ο Internet Explorer.




1. Επιλέξτε **“Configuration”**
2. Στη συνέχεια **“Network”**
3. Έπειτα επιλέξτε **“Advanced Settings”**
4. Επιλέξτε **“Wi-Fi”**
5. Στη συνέχεια, **“Enable”**
6. Έπειτα επιλέξτε **“Save”**
7. Επάνω δεξιά επιλέξτε **“Search”**
8. Εντοπίστε το SSID του Wi-Fi που θέλετε να συνδεθείτε και επιλέξτε το
9. Εισάγετε το κωδικό πρόσβασης για το Wi-Fi
10. Τέλος, επιλέξτε **“Save”** για αποθήκευση των ρυθμίσεων




1. Επιλέξτε “**Configuration**”
2. Στη συνέχεια “**Network**”
3. Έπειτα επιλέξτε “**Basic Settings**”
4. Επιλέξτε “**TCP/IP**”
5. Στη συνέχεια, “**Wlan**”
6. Στο σημείο “**Preferred DNS Server**” εισάγετε την IP του modem/router (Gateway IP) στο παράδειγμά μας είναι η 192.168.1.1

3. Λειτουργία P2P



1. Επιλέξτε “**Configuration**”
2. Στη συνέχεια “**Network**”
3. Έπειτα επιλέξτε “**Advanced Settings**”
4. Επιλέξτε “**Platform Access**”
5. Στη συνέχεια, “**Enable**”

To enable Guarding Vision service, you need to create a verification code or change the verification code.

A dialog box for creating a verification code. It has two input fields: 'Verification Code' and 'Confirm Verification Code', both containing six dots. To the right of each field is a green checkmark icon. Below the fields is a text block explaining the requirements: '6 to 12 characters allowed, including upper-case and lower-case letters, and digits. To ensure device security, a combination with at least 8 characters of all the three above mentioned types is recommended. Note: The 6-character combination "ABCDEF" and any other case sensitive combination of this alphabetical order are not allowed.' A red box highlights the entire dialog, and a red arrow points to it from the number '6.'

Verification Code

6 to 12 characters allowed, including upper-case and lower-case letters, and digits. To ensure device security, a combination with at least 8 characters of all the three above mentioned types is recommended. Note: The 6-character combination "ABCDEF" and any other case sensitive combination of this alphabetical order are not allowed.

Confirm Verification Code


The Guarding Vision service will require internet access. Please read the ["Terms of Service"](#) and ["Privacy Policy"](#) before enabling the service.

Two buttons: 'OK' and 'Cancel'. The 'OK' button is highlighted with a red box, and a red arrow points to it from the number '7.'

OK Cancel

6. Εισάγετε ένα κωδικό επαλήθευσης (Ο κωδικός πρέπει να αποτελείται συνολικά από 8-16 ψηφία, γράμματα με ένα τουλάχιστον κεφαλαίο και νούμερα)

7. Στη συνέχεια επιλέξτε “OK”

A screenshot of the 'Configuration' tab in a web interface. The left sidebar shows 'Advanced Settings' selected. The main area has tabs for 'Platform Access', 'HTTPS', 'QoS', 'Wi-Fi', 'WLAN AP', and 'Integration Protocol'. Under 'Platform Access', 'Platform Access Mode' is set to 'Guarding Vision', 'Enable' is checked, 'Server IP' is 'litedev.guardingvision.com', and 'Register Status' is 'Offline'. The 'Verification Code' field is visible with the same requirements text as in the first dialog. A red box highlights the 'Save' button at the bottom, and a red arrow points to it from the number '8.'

Live View Playback Picture Configuration

Platform Access HTTPS QoS Wi-Fi WLAN AP Integration Protocol

Platform Access Mode Guarding Vision

Enable

Server IP litedev.guardingvision.com Custom

Register Status Offline

Verification Code

6 to 12 characters allowed, including upper-case and lower-case letters, and digits. To ensure device security, a combination with at least 8 characters of all the three above mentioned types is recommended. Note: The 6-character combination "ABCDEF" and any other case sensitive combination of this alphabetical order are not allowed.

Create a verification code.

Save

8. Τέλος επιλέξτε “Save” για αποθήκευση